

Calibration Certificate

Calibration provided by : EKO Instruments Co., Ltd.
1-21-8, Hatagaya, Shibuya-ku, Tokyo, 151-0072, Japan

Manufacturer :	EKO Instruments Co., Ltd.	Issue Date :	April 26, 2021
Model :	MS-711		
Description :	Spectroradiometer	Calibration Date :	April 21, 2021
Serial Number :	S14167.01	Calibration Procedure :	110225-1.1
Accessories :		Calibration method :	Lab calibration
Certificate Number :	S14167.01-EX21-134S		

Calibration uncertainty

Wavelength range	Combined uncertainty	Exposure time settings
300nm - 350nm	+/- 17.4 %	2000ms
350nm - 450nm	+/- 5.1 %	1000ms
450nm - 1050nm	+/- 4.2 %	1000ms
1050nm - 1100nm	+/- 5.3 %	2000ms
350nm - 1100nm (wavelength accuracy)	+/- 0.2nm	-

Calibration condition

Conditions	Unit	Note
Ambient temperature	25 °C	-
Orientation of lamp filament	Vertical	-
Orientation of spectroradiometer	90 degrees Tilted	-

Standard lamp

		Note
Lamp type	OL-FEL-C Tungsten Halogen	1000W
Lamp S/N	F1620	-
Calibration date	2020/5/29	Max. 50 hours

T. Hachikawa

T. Hachikawa / Manager of Mfg. Dept.

T. Konuma

T. Konuma / Inspector

Calibration procedure

The MS-spectroradiometer is calibrated against a NIST traceable tungsten-halogen OL-FEL standard lamp at a distance of 50 cm. The standard lamp has a known spectrum and the absolute irradiance is calibrated at several wavelengths. By measuring the spectroradiometer's detector responsivity in counts as a function of the irradiance at corresponding wavelengths, the sensitivity of each photo diode array pixel is converted into absolute units ($W/m^2/\mu m$).

The calibration function is determined by averaging 10 single measurements, measured separately for 4 different wavelength intervals each with a fixed exposure time. This is to use optimal output characteristics of the detector. Finally the calibration function is uploaded to the spectroradiometer firmware for automatic conversion of measured count into absolute units.

Calibration Uncertainty

The combined uncertainty of the calibration function for each wavelength interval is based on individual uncertainties contributed by the standard lamp, calibration set-up and spectroradiometer performance properties.

Source		Uncertainty			
		300 - 350nm	350 - 450nm	450 - 900nm	900 - 1100nm
Standard Lamp calibration	Gooch&Housego	2.74%	2.26%	1.91%	1.57%
Lamp current	Calibration set-up	0.12%	0.09%	0.04%	0.02%
Measurement repeatability	Spectroradiometer	6.00%	1.00%	1.00%	2.00%
Non-Linearity	Spectroradiometer	1.00%	1.00%	1.00%	1.00%
Alignment	Calibration set-up	1.00%	1.00%	1.00%	1.00%
Temperature dependency	Spectroradiometer	0.25%	0.25%	0.25%	0.25%
Cosine response	Spectroradiometer	0.00%	0.00%	0.00%	0.00%
Stray Light	Spectroradiometer	6.00%	1.50%	0.60%	0.60%

$$\text{Uncertainty} = \left\{ \left(\text{Standard Lamp calibration} / 2 \right)^2 + \left(\text{Lamp current} / 2 \right)^2 + \left(\text{Measurement repeatability} \right)^2 + \left(\text{Non - Linearity} \right)^2 + \left(\text{Alignment} \right)^2 + \left(\text{Temperature dependency} \right)^2 + \left(\text{Cosine response} \right)^2 + \left(\text{Stray Light} \right)^2 \right\} / \sqrt{2} * 2$$

Traceability to NIST Standard

OL-FEL lamps are calibrated by direct comparison to a Gooch & Housego NIST traceable FEL 1000-Watt lamp. Gooch & Housego NIST traceable lamps are used for a maximum period of 50 hours (will be replaced afterwards).